



**IN FOCUS  
SOLUTIONS<sub>LLC</sub>**

**C5 / C6 CORVETTE  
DOOR EDGE GUARDS  
INSTALLATION INSTRUCTIONS**

**Kit Contents:**

- 2 - Door Edge Guards

**Tools Needed:**

- None

**WARNING:** Ensure you have sufficient gap between the door edge and quarter panel. Sagging or misaligned doors may cause damage to painted surfaces. Use at your own risk.

1. Clean the door edge, inside and out. Ensure the surface is totally dry before installing the guard.
2. Measure and cut door edge guard to desired length.
3. Install edge guard from top of door downward.

**C5 NOTE:** Ensure inside edge covers gap between edge and inner panel

**C6 NOTE:** Ensure inside edge sits under inner panel lip.

