



**IN FOCUS  
SOLUTIONS<sub>LLC</sub>**

**CS / C6 TRUNK / HATCH  
STRUT ASSIST KIT  
INSTALLATION INSTRUCTIONS**

**Kit Contents:**

- Strut Assist Spring
  - Spring Foot
1. Loosen 1 latch screw with Torx-30 screwdriver.

**Tools Needed:**

- Torx-30 Screwdriver

2. Slide spring under latch screw and retighten.

**NOTE:** For added strength insert the nylon washer in the base of the spring and slide the latch screw through the center of the washer and retighten.

3. Slide / twist foot onto spring.

4. Lubricate struts and hinges.

