

Kit Contents:


- 4 Tail Light Seals
- 2 Alcohol Wipes
- 1. Remove screws with Torx-15 screwdriver.

2. Remove & disconnect tail light.

3. Clean tail light & bumper of dirt & loose debris.

Tools Needed:

• Torx-15 Screwdriver



4. Clean tail light rim with alcohol wipe & allow to dry.

5. Starting in the top center of the tail light, apply seal to black plastic so rounded edge hangs slightly over the red plastic lens. Trim the end as needed.

6. Reinstall tail light & screws.

